

Kerahairproducts.com

— for professionals —

Qod Max Silver keratin treatment

Instructions

Step 1:

Wash your hair very well at least 3 times with the Qod Original Cleanse Shampoo and rinse the hair well. (Repeat these more than 3 times if it's necessary).

Step 2

Dry the hair with a towel, wrap a dry towel around the hair and leave the towel around the hair for five minutes (the hair will be now for 80% dry).

Step 3:

Shake the Qod Max Silver keratin treatment well before use. Separate the hair into 4 parts, Apply the product 1 cm far from the scalp, on the hair strands with a brush. Then use a thin comb to comb your hair, the remaining product on the comb can be reused for the next hair strand. Working from the neck upwards. Leave the Qod Max Silver Keratin Treatment for 50 minutes in the hair, with a plastic hair cap or plastic kitchen foil, the heat ensures that keratin is better absorbed into the hair.

Step 4

Carefully rinse the hair with lukewarm water for 40 seconds (without shampooing).

Step 5:

Make hair 100% dry using a hair dryer.

pay attention: to avoid hair burning and hair damage, the hair must be 100% dry. Before you use the hair straightener. From experience, we know that even after hair drying, the hair points may still be damp, make sure it is 100% dry.

Step 6:

Divide the hair into 5 parts. Take a hair lock of 1-centimeter thick and slide the hair straightener down 12 times (chemically straight or relaxed hair 5 times, the regrowth 12 times) on each hair strand. Set the hair straightener on next temperature:

*230 ° C for hair in good condition;

*210 ° C for chemically treated hair;

*190 ° C for fine and thin hair.

Working from the neck upwards.

Step 7

After step 5 apply a drop of hair serum into the hair and don't wash the hair for 48 hours (two days).

pay attention: The hair may only be treated and washed with keratin after care products.